

Read assembly instructions carefully before assembling. Ensure you have the right tools to complete assembly (Hammer & Philips Head Screw Driver). Always work on solid, level, clean and flat surface. **DO NOT WORK ON CARPET.** Do not climb on the product. Do not place heavy articles on top shelf or on the top of product. Use only for intended purpose. Failure to follow instructions can result in serious injury.

Caution: The unit may tip forward when opened empty, if not secured with the wall.

TWO DOOR ROBE UNIT

(Assembly Instructions)

- 1) Lay down the top on a protected surface with holes facing up and push the plastic connectors into holes (Diagram 1). Please note that top, fix shelf and bottom are same.
- 2) Lay both cabinet end panels on a flat protected surface with holes facing up and melamine edge facing opposite to each other. Please note that both cabinet end panels look similar as left and right end panels are reversible. Push the dowels gently (do not hammer) into their 5mm dowel holes.
- 3) Attach the top and bottom to the left cabinet end ensuring that the connectors face to the top of the unit and melamine edge strips are facing to the front of the unit. Attach the fix shelf to the unit with plastic connectors facing to the bottom of the unit and edge strip facing to the front of the unit. Please make sure that the top, fix shelf and bottom is pushed tightly against the end panel before tightening the screws. Fit the toe rail (Diagram 2).
- 4) Fix the right cabinet end by carefully aligning the holes in the cabinet end with the plastic connectors and secure the cabinet end by tightening the screws of plastic connectors.
- 5) Lay unit face down on a protected surface to avoid damaging melamine edges and position the back panels against the top rear of the unit (approximately 3 mm in from the top edge) with white side facing inward. Insert the plastic joining strips in the gap between the back panels (long joining strip below middle shelf and small joining strip above middle shelf). Press the back panels along the joining strips so that the gap on both side (between cabinet end and back panel is approximately 3 mm). Ensuring that the cabinet is square, nail the back panels along all the edges taking care to avoid nail breakage through the surface of the fix shelves and cabinet ends.
- 6) While unit is lying face down, attach the four glides on the underside corners of the cabinet end panels.
- 7) **Two Persons Lift Recommended.** Stand the unit straight. Separate the hinge mounting plates from hinges (Diagram 3). Secure the three hinge mounting plates to the inside of left cabinet end. Repeat for right cabinet end. While tightening the screws, please make sure to tighten the screws straight in.
- 8) Lay the door panels on a solid, flat and protected surface with holes facing upwards. These panels can easily be identified by large 26 mm diameter holes. Attach hinge to the door panel by positioning the body of hinge in large 26 mm holes and secure in place using hinge screws. Repeat for other two hinges (Diagram 4). Now, hold the door straight against the unit so that hole in the hinge plate is in line with hole in the hinge (Diagram 6) and secure the hinge with the screw removed in last step. Fix handle onto the door using handle screws. Repeat for the other door. **Caution: Unit may tip forward, when assembling the doors, if unit is not secured with the wall.**
- 9) Insert the rail supports into the holes provided and inset the metallic robe rail between the supports.
- 10) The following instructions should be followed to adjust hinges if the gap between the doors is too wide or narrow (Diagram 5 & 6):
 - Screw 1 is used for adjustment
 - Screw 2 is used to secure hinge to cabinet end
 - a. Start from the top hinge.
 - b. Loosen screw 2 by turning screw in an anticlockwise direction.
 - c. Now, turn screw 1 in a clockwise direction (the amount to turn this screw is determined by the width of the gap between the doors).
 - d. Tighten screw 2 by turning in a clockwise direction.
 - e. Repeat these steps for the centre hinge and bottom hinge.
 - f. Repeat these steps again with the other door.
 - g. Check gap between cabinet doors (should be approx. 2mm), if not, repeat steps a to f.

If you need to contact us regarding the unit, please call 1800 822 823 and quote the batch number shown on the carton.

